


SUMMER Installation Schematics


There are two types of installation:


Concealed SUMMER Tank system or Exposed SUMMER Tank system

Standard Installation

	<p>Exposed SUMMER Tank system is classic installation method which incorporates the SUMMER Tank and SUMMER Collector on the roof itself.</p> <p>This method is Standard – cheapest to install as it is the easiest method for any roof installation.</p>
---	--

Aesthetic Installation

	<p>Concealed SUMMER tank system is installed under the roof to make the roof more aesthetically pleasing.</p>
---	---

	<p>SUMMER works by a physics principal called <i>thermosyphon</i>. SUMMER Tank has to be installed above the SUMMER Panel.</p> <p>A force circulation pump must be installed if the SUMMER Tank is to be placed below the SUMMER Panel. (refer figure)</p>
---	--